

## SAFETY KNIFE CUTX BASIC X6040 MULTICUT MAX40



### All-purpose cutter with an extra long blade


Do you need a cutter with a long, stable blade? Then the MultiCut MAX40 CUTX BASIC X6040 will inspire you! The top slide in freewheeling mode, which should be used above all for vertical cuts, has proven itself. The MultiCut MAX40 CUTX BASIC X6040 cuts all conventional packaging. Due to its low weight, it is easy on your wrist even with frequent use and, thanks to its gently rounded shape, sits comfortably in the hand. A cord can be pulled through the screw at the end of the handle. Automatic blade retraction and easy blade change. The blade can either be operated from above or from the side. For right and left handers.

### Security certificate

GS certificate: Nr. 187282 - 7551 - 13737 - 2023  
Date of issue: 19.10.2023  
applies to: Art. 3010159  
Art. 3010130



### Dimensions & Details

Variations:	Art. 3010159, grey-black Art. 3010130, detect blue Art. 3010114, white-black other colours on request
Packing unit:	Individual packaging
Dimensions (L x B x H):	142 x 31 x 15 mm
Product weight:	42g
Cutting depth:	40 mm
Base Material:	plastic
Security level:	1  automatic blade retraction
EAN-Code Art. 3010159:	4251946400362
EAN-Code Art. 3010130:	4251946400300
EAN-Code Art. 3010114:	4251946400256
Customs tariff number:	82119300

### extra long blade and variable handling

The main difference between the MultiCut MAX40 CUTX BASIC X6040 and our MultiCut MAX CUTX BASIC X6060 is the significantly longer, stable blade. This can be operated both from the side and from above. When operating with the upper slide, you can exert significantly more pressure on the material to be cut when making vertical cuts. As with the MultiCut MAX CUTX BASIC X6060, the handle is pleasantly light in the hand and the blade is of course also suitable for all common packaging.

### Well kept

Would you like to have your MultiCut MAX40 CUTX BASIC X6040 at hand in a fixed location? A cord (max. 3 mm diameter) can be pulled through the screw at the end of the handle. This allows you to hang the MultiCut MAX40 CUTX BASIC X6040 in a meaningful place. Of course, it also fits in your pocket if you want to have it with you.

### Sustainable

We want to do our bit: CUTX safety knives are made in Solingen / Germany from up to 80% recyclable plastic. We use sustainable energy for production and assembly, including from our own solar power system.

Our extensive experience in knife production also guarantees consistently high quality and durability.

You can also do your bit: we take back old cutting tools and recycle them properly. Please contact us: mail@cutx.info

### Printing and special colours possible

Our items are also available in your favorite colours. In addition, they can be printed, so that you have here an excellent and individual advertising medium, which your customers will certainly take at hand again and again.

### Application Areas

CUTX safety knives assist you in your day-to-day work and protect the goods in the packaging with their short blade.

Cutting of:  
Cardboard, paper, adhesive tape, strapping tape, foil  
For right- and left-handed people.



foil



Cardboard



strapping tape



adhesive tape



paper

# Technical information

Safty knife  
CUTX BASIC X6040




## Easy blade change

Your two hands are sufficient as an aid. Simply set the screw horizontally at the end of the handle, slide the blade holder all the way forward, open the cover downwards and replace the blade. Complete.

## Spare parts / blades

The replacement blades are supplied in dispensers of 10 each.  
H10008 Trapezoid blade



Open the locking screw by turning to the left

Blade holder slide out

Open the blade cover

Changing the blade  
Blade type: H10008  
or comparable blades  
with the same dimen-  
sions

Close the blade cover


Slide in the blade holder  
and close the locking  
screw by turning it to  
the right



see also safety instructions

## Safe handling

Push out the blade, put it on, release sliders. The automatic blade retraction ensures that the blade automatically slides back into the housing as soon as the cutting material is left.



Slide the blade on the side or top  
slide forward

Fit the blade and re-  
lease the blade holder

At the end of the cut, the blade  
holder springs back into the end  
position

## Safety instructions

Please read the instructions carefully and keep them to ensure prolonged and safe use of our cutting tools.

This product is only approved for manual cutting and must not be used for purposes other than those for which it is intended. Care must be taken to ensure correct handling and use.

Avoid injury: Only use cutting tools that are in good condition and have sharp, undamaged blades. Exercise caution when handling this product. Be sure to familiarise yourself with its handling and operation beforehand. The sharp blade can cause serious cuts. Do not hold the blade, do not place your other hand along the cutting path of the cutter and always cut past your body. Replace blunt blades quickly and dispose of them properly.

Tighten the cutter to avoid injury. Store the cutter in a safe place.

Keep the cutter clean and do not expose it unnecessarily to dust, dirt and moisture to ensure longevity.

**No liability is accepted for consequential damage.**  
**Subject to technical changes and errors!**  
**This product should not be used by children!**

